


# **Emerald Planet Lower Door Seal**

### Installation Guide


#### 1) Assessment


a) Determine whether the seal should be attached to the inside or outside of the door. If it works equally well on either choose the inside of the door.



# 2) Measurement

- a) Before removing the adhesive backing, determine the correct position of the door seal.
- b) Mark the correct position on the door (The flexible strip should form a light seal with the floor when closed and move smoothly across the floor when the door is opening/closing.)
- c) Cut the door seal to the required length using hand shears (i.e. Tin Snips or Garden Secateurs/Pruning Shears).





### 3) Surface Preparation

- a) Ensure the surface of the door where the door seal will be affixed is dry, smooth, clean and if painted, well cured.
- b) If cleaning is required, ensure all cleaning products are wiped from the surface before installation.



## 4) Application

- a) With the door in a closed position, remove the adhesive backing and affix the door seal to the marked position on the door and press firmly.
- b) Best results are achieved when adhesion temperature is at least 20°C. If possible, allow to cure fully before opening the door. Full adhesion strength may take a few days.



www.emeraldplanet.com.au | 1300 511 148 | ABN 24 134 393 016 Sydney 2/29 Mitchell Road, Brookvale NSW 2100







